

Single Pilot Resource Management (SRM) Crew Resource Management (CRM)

*These callouts should be memorized and practiced during flight.
When flying with two pilots, the pilot flying flies the airplane, and the pilot monitoring calls these out.*

Condition / Location		Pilot Flying (PF) or Pilot Monitoring (PM)
Engine Starting	During Engine Start	<i>“oil pressure”</i>
	During Takeoff	<i>“power normal” or “abort”</i>
Anytime	Airspeed 5 knots or more below target airspeed	<i>“airspeed”</i>
	Altitude 200 feet above or below target	<i>“altitude”</i>
Climb	1000 ft below assigned altitude	<i>“one thousand to go”</i>
Descent	1000 ft above assigned altitude	<i>“one thousand to go”</i>
Descent	VSI exceeds 1200 feet per minute	<i>“sink rate”</i>
Approach	First Positive Inward motion of localizer needle	<i>“localizer alive” or “course alive”</i> (when captured, “localizer” or “course” captured)
	First Positive motion of glideslope needle	<i>“glideslope alive”</i> (when captured, “glideslope” or “glidepath” captured)
	If more that one dot from GS/GP	<i>“glideslope” or “glidepath”</i>
	If more that one dot from Localizer	<i>“localizer” or “course”</i>
	Visual Descent Point	<i>“VDP”</i>
	200' above minimums	<i>“200' above”</i>
	100' above minimums	<i>“100' above”</i>
	Reaching Decision Height, Minimum Descent Altitude, or Missed Approach Point	<i>“minimums” or “approach/lights” or “runway in sight” or “no runway missed approach”</i>
	Loosing Runway Environment	<i>“missed approach”</i>
Transfer of Controls		Pilot flying <i>“Your Controls”</i> followed by pilot monitoring acknowledgment <i>“My Controls”</i>
Autopilot On	HDG or NAV	<i>“Autopilot Engaged HEADING” or “Autopilot Engaged NAV”</i>
	VS	<i>“Vertical Speed XXX FPM Climb Altitude Armed” or “Vertical Speed XXX FPM Descent Altitude Armed”</i>
	APP	<i>“Approach Armed” “Approach Captured” “Glideslope Armed” “Glideslope Captured”</i>
Autopilot Off		<i>“Autopilot Disengaged”</i>