1.	Aborted Takeoff	2
2.	Cabin Alt 10,000' Warning	2
3.	Cabin/Cockpit Fire, Smoke or Fumes	2
4.	Emergency Braking	2
5.	Emergency Evacuation	2
6.	Engine Failure During Approach	2
7.	Engine Failure During Takeoff Above V1	2
8.	Engine Failure During Takeoff Below V1	2
9.	Engine Fire - Shutdown	2
10	Fuel Press Light	3
11	Overspeed Recovery - Overspeed Warning Horn	3
12	Pitch Axis Malfunction	3
13	Roll or Yaw Axis Malfunction	3
14	Stall Warning Activates	3
15	Thrust Reverser - Deploy During Takeoff	3
16	Thrust Reverser Deployment During Takeoff Above V1	3
17	Thrust Reverser Deployment During Takeoff Above V1	3
18	Thrust Reverser Deployment During Takeoff Below V1	3

## Lear 35A Alphabetical Emergency Procedures

Aborted Takeoff	<ol> <li>Thrust Levers IDLE</li> <li>Wheel Brakes APPLY</li> <li>Spoilers EXTENDED</li> </ol>
Cabin Alt 10,000' Warning (Emergency Descent)	<ol> <li>Crew Oxygen Masks DON &amp; Select 100%</li> <li>Thrust levers IDLE</li> <li>Autopilot DISENGAGE</li> <li>Spoilers EXTEND</li> <li>Landing Gear (below Mmo or VIe) DOWN</li> <li>Descend at Mmo/VIe but not below MSA</li> <li>PASS OXY Valve NORMAL</li> <li>PASS MASK Valve MAN</li> </ol>
Cabin/Cockpit Fire, Smoke or Fumes	<ol> <li>Crew Oxygen Masks DON &amp; SELECT 100%</li> <li>Smoke Goggles DON IF AVAILABLE</li> <li>Passenger Oxygen Masks DEPLOY</li> <li>OXY-MIC Switches ON</li> <li>If source is not immediately known - Land as soon as possible If source is known - Extinguish fire or eliminate smoke or fumes If it cannot be verified fire is out - Land as soon as possible If fire is out - Land as soon as practical</li> </ol>
Emergency Braking	Emergency Brake Handle PULL OUT     Emergency Brake Handle PUSH DOWNWARD
Emergency Evacuation	<ol> <li>Stop the aircraft</li> <li>Parking Brake SET</li> <li>Thrust levers CUTOFF</li> <li>If an engine fire is suspected         <ul> <li>Applicable Engine Fire Handle PULL</li> <li>ARMED Light DEPRESS ONE</li> <li>Other Engine Fire Pull Handle PULL</li> <li>If engine fire is not suspected:</li></ul></li></ol>
Engine Failure During Approach	Control Wheel Master Switch DEPRESS AND RELEASE     Thrust Lever (operative engine) INCREASE AS REQ'D     Flaps 20 MAX     Airspeed VREF + 10 MIN
Engine Failure During Takeoff Above V1	<ol> <li>Rudder &amp; Ailerons AS REQ'D</li> <li>Accelerate to Vr Keep nose wheel on Runway</li> <li>Rotate at Vr; Climb at V2</li> <li>Positive Rate GEAR UP</li> <li>Clear of Obstacles V2+30 FLAPS UP</li> </ol>
Engine Failure During Takeoff Below V1	<ol> <li>Thrust Levers IDLE</li> <li>Wheel Brakes APPLY</li> <li>Spoilers EXTEND (T/R or D/C Deploy if Necessary)</li> </ol>
Engine Fire - Shutdown	<ol> <li>Thrust Lever IDLE UNLESS CRITICAL THRUST SITUATION</li> <li>If fire continues more than 15 seconds or there are other indications of fire:         <ul> <li>a. Thrust Lever CUTOFF</li> <li>b. Engine Fire Pull Handle PULL</li> <li>c. ARMED Light DEPRESS ONE</li> </ul> </li> </ol>

Fuel Press Light	<ol> <li>Thrust Lever RETARD</li> <li>Standby Pump ON</li> <li>Air Ignition ON</li> </ol>
Overspeed Recovery - Overspeed Warning Horn	<ol> <li>Thrust Levers IDLE</li> <li>Autopilot DISENGAGE</li> <li>Identify Aircraft Pitch and Roll Attitude</li> <li>Level Wings</li> <li>Elevator and Pitch Trim NOSE UP AS REQ'D         If Mach or Airspeed is severe or if pitch and/or roll attitude is extreme or unknown:     </li> <li>Landing Gear DOWN, DO NOT RETRACT</li> </ol>
Pitch Axis Malfunction	<ol> <li>Control Wheel Master Switch DEPRESS AND HOLD</li> <li>Attitude Control AS REQ'D</li> <li>Thrust Levers:         <ul> <li>If high-speed nose-down attitude IDLE</li> <li>If near stall INCREASE AS REQ'D</li> </ul> </li> <li>Both Stall Warning Switches OFF</li> <li>Pitch Trim Switch OFF</li> <li>Autopilot Switch OFF</li> </ol>
Roll or Yaw Axis Malfunction	<ol> <li>Control Wheel Master Switch DEPRESS</li> <li>Attitude Control AS REQ'D         If control force continues</li> <li>Airspeed REDUCE</li> <li>Affected Axis Trim CB - ROLL or YAW TRIM (pilot's ESS bus) PULL</li> </ol>
Stall Warning Activates	<ol> <li>Lower Pitch Attitude to reduce angle of attack</li> <li>Thrust Levers TAKEOFF POWER</li> <li>Accelerate out of the stall condition</li> </ol>
Thrust Reverser - Deploy During Takeoff	<ol> <li>Emer Stow Switch EMER</li> <li>Throttle IDLE</li> <li>Positive Rate of Climb GEAR UP</li> <li>Clear of Obstacles V2+10 FLAPS UP</li> <li>Maximum Airspeed (until stowed) 125 KIAS</li> </ol>
Thrust Reverser Deployment During Takeoff Above V1 With AERONCA T/R's	<ol> <li>Rudder and Ailerons AS REQ'D</li> <li>Thrust Lever (affected engine) IDLE</li> <li>Emer Stow Switch EMER STOW</li> <li>Accelerate to Vr Keep nose wheel on runway</li> <li>Rotate at Vr Climb at V2</li> <li>Positive Rate of Climb Established GEAR UP</li> <li>Clear of Obstacles ACCELERATE TO V2+30, FLAPS UP</li> </ol>
Thrust Reverser Deployment During Takeoff Above V1 With T/R 4000 T/R's	<ol> <li>Rudder and Ailerons AS REQ'D</li> <li>Thrust Lever (affected engine) IDLE</li> <li>Thrust Reverser Control Switch OFF</li> <li>Accelerate to Vr Keep nose wheel on runway</li> <li>Rotate at Vr Climb at V2</li> <li>Positive Rate of Climb Established GEAR UP</li> <li>Clear of Obstacles ACCELERATE TO V2+30, FLAPS UP If DEPLOY Lights stay on:</li> <li>Thrust Lever (affected engine) CUTOFF</li> </ol>
Thrust Reverser Deployment During Takeoff Below V1	<ol> <li>Thrust Levers IDLE</li> <li>Wheel Brakes APPLY</li> <li>Spoilers EXTEND</li> </ol>